

INSTALLATION INSTRUCTIONS

POWER END TERMINATION KIT

DESCRIPTION


The Power End Termination Kit is for use with all self-regulating heater cables. Compatible for use with any vendor's heater cables smaller than 11mm (0.44") diameter.

KIT CONTENTS

Power Terminations
Tube of Silicone


OVERJACKET PRODUCTS

For Braided Products proceed to step 4 below.




WARNING:
DO NOT CUT BRAID


- ① Lightly cut around heater overjacket 127mm (5") from the end. Bend cable to break the overjacket.
- ② Lightly cut overjacket up the center between first cut mark and the cable end. Bend cable to break the overjacket.




- ③ Remove overjacket from heater cable.




- ④ Move braid back toward the overjacket, creating a bulge.



- ⑤ At the bulge, separate the braid to make an opening.




- ⑥ While bending the heater cable, work it through the braid opening.




- ⑦ Pull the braid tight.
- ⑧ Proceed to "Self-regulating Products", sheet 2.

FOR ALL SELF-REGULATING PRODUCTS


(See sheet 3 for alternate method on high temperature products.)




- ① Lightly cut around cable outer jacket 102mm (4") from the end. Bend cable to break outer jacket.
- ② Lightly cut the outer jacket up the center between the first cut mark & the cable end. Bend cable to break outer jacket.




- ③ Remove the jacket from the heater cable.



- ⑤ Starting at the end, pull each bus wire away from the core material.
- ⑥ Remove exposed core material.




- ⑦ Cut 6mm (0.25") off the end of each bus wire.
- ⑧ Proceed to "Power Termination" on sheet 4.




WARNING:
DO NOT CUT BUS WIRES

- ④ Shave the core material from the outside of each bus wire.


High Temperature Cable - ALTERNATE STRIPPING METHOD




- ① Lightly cut around cable outer jacket 102mm (4") from the end. Bend cable to break outer jacket.
- ② Lightly cut the outer jacket up the center between the first cut mark & the cable end. Bend cable to break outer jacket.




- ③ Remove the jacket from the heater cable.




- ④ Make a cut inside each bus wire.



- ⑤ Starting at the end, in the same plane as the cable, pull each bus wire away from the core material.



- ⑥ Remove the exposed core material.




- ⑦ Remove the remaining core material off the outside of each bus wire.
- ⑧ Cut 6mm (0.25") off the end of each bus wire.
- ⑨ Proceed to "Power Termination" on sheet 4.


POWER TERMINATION

⚠️ WARNING:

- Bus wires must not touch or cross while inserting into power termination.
- Only power terminations / end seals specifically approved for the vendor's style and type of heater cable must be used.



- ① Insert bus wires into power termination.
- ② Squeeze power termination opening and fill with silicone.



- ③ Push power termination to overlap jacket.
- ④ The silicone will set up in about 30 minutes with a complete cure after 24 hours.

⚠️ WARNING:

- Do not megger or hi-pot until silicone is completely cured.
- Braid must be kept away from bus wires or shorting will occur.